

# Automatic load transfer switch

# Standard features (all control types)

- 1 x Pair of contactors or circuit breakers, mechanically and electrically interlocked
- 1 x Set of control and monitoring fuses
- 1 x Set of generator, mains and load terminations

#### 0 - 800 Amp

Mechanically and electrically interlocked contactors are used for the load transfer switch. Fitted in proprietary manufactured wall mounting cubicles with hinged front access door and removable gland plates to the top and base. Finished in grey RAL7032.



Mechanically and electrically interlocked moulded case circuit breakers (non-auto) with motor operators are used for the load transfer switch. Fitted in proprietary manufactured floor standing cubicles with hinged front access door and removable side and rear panels for ease of installation. Removable gland plates to the top and base. Finished in grey RAL7032.

#### 2000 - 6300 Amp

Mechanically and electrically interlocked air circuit breakers (non-auto) with motor operators are used for the load transfer switch. Fitted in proprietary manufactured floor standing cubicles with hinged front access door and removable side and rear panels for ease of installation. Removable gland plates to the top and base. Finished in grey RAL7032.

Contactors can be used on higher ratings and circuit breakers on lower ratings.



**Additional features** 

| 3 phase mains detection       | * | * | * | * |
|-------------------------------|---|---|---|---|
| 1 phase generator detection   |   |   | * | * |
| Mimic display                 |   | * |   | * |
| Generator available indicator |   | * | * | * |
| Generator on load indicator   | * | * | * | * |
| Mains available indicator     |   | * | * | * |
| Mains on load indicator       | * | * | * | * |
| Key switch selector *         |   |   |   | * |
| Delay on start timer          |   |   | * | * |
| Delay on stop timer           |   |   | * | * |
| Delay on restoration timer    |   |   | * | * |
| Settle delay timer            |   |   |   | * |
| Transfer delay (s)            |   | * | * | * |
| Volt free contacts            |   |   |   | * |

<sup>\* 4</sup> position key switch - "Auto mode", "Auto mode with manual mains restoration", "Run generator off load" and "Run generator on Load".

### **Blades Power Generation**



# Automatic load transfer switch

# **Specifications**

All components meet relevant European standards and regulations.

Panel meters IEC51 BS89

IP52 -25+50°c

Ammeters/voltmeters Class 1.5

Frequency meters Class 0.5

Selector switches IEC73, 529

Circuit breakers;


MCCB (non-auto) IEC 947-3

ACB (non-auto) IEC 947-3

Contactors IEC 947-4-1

All contactors are rated AC1 (resistive) @ 40 degrees C. AC3 ratings are available on request.

#### **Dimensions**



|            | Н    | W    | D   |
|------------|------|------|-----|
| 0-140A     | 500  | 400  | 200 |
| 160-275A   | 800  | 600  | 300 |
| 350-550A   | 1000 | 800  | 300 |
| 700-800A   | 1200 | 800  | 400 |
| 1000-2000A | 1600 | 1000 | 500 |
| 2500-4000A | 2000 | 1000 | 800 |
| 5000-6300A | 2000 | 1200 | 800 |

NOTE: Certain combinations of additional options may require a larger enclosure.